


## Wireless Setup guide – Fritz! Box 7530

### Login to Web User Interface

- 1 Connect a computer and the **Fritz! Box 7530** using an Ethernet cable. (A yellow Ethernet cable was provided with your modem).
- 2 Open a web browser (such as Google Chrome or Mozilla Firefox), type following address into the address bar and press Enter.

You can either enter <http://fritz.box> or the IP address of the FRITZ!Box (<http://192.168.178.1> in the factory settings) to open the user interface. In addition, you can always use the emergency IP <http://169.254.1.1> to access the FRITZ!Box.




- 3 Enter the following credentials in the Username and Password fields:  
Username: **admin**  
Password: **Password is indicated at the bottom of the modem sticker**


### Sample:




- 4 Click "Wireless" ("WLAN") in the FRITZ!Box user interface then **Radio Network**.



- 5 You may update the SSID or Network Name here, then click **Apply**.



- 6 Click on Security to access the Wi-Fi Password. You may update the password on the Network Key field and click on **Apply** at the bottom once set.



- 7 Make sure you save your Wi-Fi Password somewhere secured and accessible in case you need it in the future.